

FIG. 1




FIG. 2




FIG. 3




FIG. 4A




FIG. 4B




FIG. 4C




FIG. 4D




FIG. 5A




FIG. 5B




FIG. 6




FIG. 7

Address:
helpdesk@metr8.com

950
↙

1. Subject:
2. **Machine call (MC);** Received TAG ID#yyyyy
3. Content:
4. Customer name
5. Customer address
6. Customer phone number
7. Model name
8. Copier S/N
9. TAG ID#
10. SC code number
11. Receive date and time

FIG. 8 A

960




FIG. 8B

03/01/01 07:28 PM




FIG. 9




FIG. 10





FIG. 11A






Fig. 12A




Fig. 12B




Fig. 12C

1400

CALL LIST

SEQ	SO	CH-STMER	MODEL	machine notification call	CAUSE/ SOLUTION INPUT	LC LIST	CALL TIME RECEIVED	ELAPSED TIME	OPERATOR
1	1410	1414	1416	1418	1420	1422	1424	1428	1430
1	metro sales	office company 1	A 050	MC			12:00	00:30	Greg
2	metro sales	office company 2	A 050	SC			1:00	00:15	Joan
:									
n	metro sales	office company 2	A 000	TEL			3:15	00:42	Greg

FIG. 13

CALL DETAIL

Symptom, Cause and Solution

Symptom	Manual Call
Cause	
Solution	

~ 1510

L-ADP/Copier Information

Date Received	03-02-2001 09:28
Customer	Ricoh
Installed Section	Floor
Contact	Tel
Model/Serial Number	Aficio850 / H3600300601
Particular Notes	
Tag ID	NSC 850
SO / SD	RC(TEST) / RC(TEST) Service

~ 1520

Unsettled

SEQ	SC	Time Received	Elapsed Time
1	TEL	08:49	50:46

~ 1530

READ/WRITE

~ 1540

MACHINE CONDITION DATA

~ 1550

SERVICE CALL/JAMDATA

~ 1560

CALL HISTORY

~ 1570

LOOP TEST

~ 1580

EXECUTE

~ 1582

READ

~ 1584

↑ 1500

FIG. 14A

SERVICE CALL AND JAM DATA

OBLON, SPIVAK, ET AL
DOCKET #: 215760US28
INV: Gregory WRIGHT
SHEET 23 OF 40

L-ADP/Copier Information

Date Received	03-02-2001 09:28
Customer	Ricoh
Installed Section	Floor
Contact	Tel
Model/Serial Number	Aficio850/ H3600300601
Particular Notes	
Tag ID	NSC 850
SO / SD	RC(TEST)/ RC(TEST) Service

SC and Jam Data

No.	Item	Result
1	Machine Condition	2
2	SC Details	sp_wcom.c LINE:1288 VAL :-13
3	Total Paper Jams	0057
4	Total P.Jams by Tray 1	0002
5	Total P.Jams by Tray 2	0004
6	Total P.Jams by LCT(Tray 3)	0001
7	Total P.Jams by LCT Exit	0002
8	Total P.Jams by Registration	0006
9	Total P.Jams by Exit	0005
10	Total Original Jams	0079
11	Total P.Jams by Dup.Entrance	0005
12	Total P.Jams by Dup.Trans.3	0001
13	Total P.Jams by Inverter	0006
14	Total P.Jams by Fin.Entrance	0005
15	Total P.Jams by Fin. Exit	0001
16	Total P.Jams by Fin.Shift T	0006
17	Total P.Jams by Fin.Staple 1	0005
18	Total P.Jams by Fin.Staple 2	0007
19	Total P.Jams by Fin.Staple 3	0001
20	Total Orig'l Jams:ADF Feed	0070
21	Total Orig'l Jams:ADF Exit	0009
22	Total P.Jams by LT(S)	0048
23	Total P.Jams by Other Size	0002
24	Total P.Jams by DLT	0002
25	Total P.Jams by LG	0001
26	Total P.Jams by LT(L)	0004
27	P.Jams History:Latest 0	232632616
28	P.Jams History:Latest 1	232630278
29	P.Jams History:Latest 2	282630277

FIG.14B

READ/WRITE IMAGE MACHINE DATA

L-ADP/Copier Information

Date Received	02-27 -2001 10:27
Customer	Ricoh
Installed Section	Floor
Contact	Tel
Model/Serial Number	Aficio850/ H3600300601
Particular Notes	
Tag ID	NSC 850
SO / SD	RC(TEST)/ RC(TEST) Service

1610

Read/Write Items

No.	Item	Standard	Tolerance	reference parameters	current parameters	New
1	L Edge Regist. Adj.PT:1001-1	+00	-90 +90	0.1	0.5	
2	L Edge Regist. Adj.DT:1001-2	+00	-90 +90	0	0	
3	S-to-S Regist. Adj.T1:1002-1	-15	-90 +90	-3.9	-3.9	
4	S-to-S Regist. Adj.T2:1002-2	-15	-90 +90	-2.7	-5	
5	S-to-S Regist. Adj.T3:1002-3	-15	-90 +90	-3		
6	S-to-S Regist. Adj.T4:1002-4	-25	-90 +90	-2		
7	S-to-S Regist. Adj.T5:1002-5	-25	-90 +90	-2		
8	S-to-S Regist. Adj.T6:1002-6	-25	-90 +90	-1.5		
9	S-to-S Regist. Adj.DT:1002-7	-30	-90 +90	-3.7		
10	FusingTemp.Adj.Stndby:1105-1	173/178	168 178	173	179	

1620a

FIG. 15A

1600

053634 10304

1620b

11	C FusingTemp.Adj.	015	000 - 020	015	-5	
12	C FusingTemp.Adj.A4/LT :1105-4	010	000 - 020	+10	15	
13	C Web M.Cont'l Disp/Adj:1902-1	0	000 - 102	102		
14	C C.Corona Bals Adj. IA:2001-1	1000	0600 - 1300	1000		
15	C C.Corona Bals Adj. ID:2001-2	800	0600 - 1300	0800		
16	C Erase Mgn Adj.L-Edge :2101-1	25	00 - 90	0.25		
17	C Erase Mgn Adj.T-Edge :2101-2	25	00 - 90	0.23		
18	C Erase Mgn Adj.Left :2101-3	20	00 - 90	0.2		
19	C Erase Mgn Adj.Right :2101-4	20	00 - 90	0.27		
20	C Development Bias Adj.:2201-1	530	200 - 700	620		
21	C Toner Supply Mode Set:2208-1	0	0 - 1	0		
22	C Toner Supply Rate Set:2209-1	0800/1k	0100 - 2000	0800		
23	C Vref Manual Setting :2220	250	160 - 350	203		
24	C T.Current Adj.1stSide:2301-1	120/140	010 - 200	140		
25	C T.Current Adj.Thick :2301-2	120/140	010 - 200	120		
26	C T.Current Adj.OHP :2301-3	140/140	010 - 200	140		

Fig 15 B

1620C

27	C T.Current Adj.Transp.:2301-4	120/140	010 - 200	140	
28	C T.Current Adj.2ndSide:2301-5	120/140	010 - 200	120	
29	C T.Current Adj.Bet.P :2301-6	20	010 - 200	020	
30	C Cleaning Interval Set:2506-1	1	0 - 1	1	
31	C Cleaning Interval Adj:2506-2	030	001 - 100	030	
32	C Vcount Manual Setting:2906	097	040 - 240	0.96	
33	C ID Sensor Initial Set:3001-1	62	000 - 255	061	
34	C Scan.Sub Scan Mag. Adj.:4008	+0	-9 - +9	0	
35	C Scan.L-Edge Regist. Adj:4010	+00	-90 - +90	-0.7	
36	C Scan.S-to-S Regist. Adj:4011	+00	-60 - +60	-0.6	
37	C SBU Set:4902-25(Factory Use)	117	000 - 255	143	
38	C Paper Tray Priority Set(UT)	1	1 - 6	1	
39	C A.P.S. Priority Setting(UT)	0	0 - 1	0	
40	C A.I.D. Priority Setting(UT)	0	0 - 1	0	
41	C Panel Tone on/off Set(UT)	2	0 - 3	2	
42	C Preset R/E Retio Key1 (UT)	025	025 - 400	025	

FIG.15C

0996334 40304

[illegible]

FIG 15D

1620E

59	C Tray 5:Paper Type Set (UT)	0	0 - 7	0	
60	C Tray 6:Paper Type Set (UT)	0	0 - 4	0	
61	C Max.Copy Quantity Set(UT)	9999	0001 - 9999	9999	
62	C Tray 1:Paper Size Set (UT)	005	000 - 255	038	
63	C Tray 2:Paper Size Set (UT)	005	000 - 255	166	
64	C Tray 3:Paper Size Set (UT)	005	000 - 255	160	
65	C Tray 6:Paper Size Set (UT)	005	000 - 255	038	
66	C System Reset Timer Set(UT)	060	000 - 999	060	
67	C Copy Reset Timer Set(UT)	060	000 - 999	060	
68	C Panel Off Timer Setting(UT)	060	000 - 999	999	
69	C Auto Tray Switching Set(UT)	0	0 - 2	0	
70	C A3/DLT Double Count Set:5104	0	0 - 1	0	
71	C Border Erase Width Set(UT)	03	01 - 20	04	
72	C Combine Orig.Shadow Erase	0	0 - 1	0	
73	C Center Erase width Set(UT)	03	01 - 20	04	
74	C 1-2Dup.Auto Margin Adj.Set	0	0 - 1	1	

FIG. 15E

1620F

75	<input type="checkbox"/> Disable Copying:SP5118	0	0 - 1	0	
76	<input type="checkbox"/> Date/Time Set(y;m;d;h;m;w)		***** - *****	2001022711332	
77	<input type="checkbox"/> SetWeeklyTimer:SUN:ON (h;m)	9999	0000 - 9999	9999	
78	<input type="checkbox"/> SetWeeklyTimer:SUN:OFF (h;m)	9999	0000 - 9999	9999	
79	<input type="checkbox"/> SetWeeklyTimer:MON:ON (h;m)	9999	0000 - 9999	9999	
80	<input type="checkbox"/> SetWeeklyTimer:MON:OFF (h;m)	9999	0000 - 9999	9999	
81	<input type="checkbox"/> SetWeeklyTimer:TUE:ON (h;m)	9999	0000 - 9999	9999	
82	<input type="checkbox"/> SetWeeklyTimer:TUE:OFF (h;m)	9999	0000 - 9999	9999	
83	<input type="checkbox"/> SetWeeklyTimer:WED:ON (h;m)	9999	0000 - 9999	9999	
84	<input type="checkbox"/> SetWeeklyTimer:WED:OFF (h;m)	9999	0000 - 9999	9999	
85	<input type="checkbox"/> SetWeeklyTimer:THU:ON (h;m)	9999	0000 - 9999	9999	
86	<input type="checkbox"/> SetWeeklyTimer:THU:OFF (h;m)	9999	0000 - 9999	9999	
87	<input type="checkbox"/> SetWeeklyTimer:FRI:ON(h;m)	9999	0000 - 9999	9999	
88	<input type="checkbox"/> SetWeeklyTimer:FRI:OFF (h;m)	9999	0000 - 9999	9999	
89	<input type="checkbox"/> SetWeeklyTimer:FRI:ON(h;m)	9999	0000 - 9999	9999	
90	<input type="checkbox"/> SetWeeklyTimer:FRI:OFF (h;m)	9999	0000 - 9999	9999	

FIG. 15F

09566334 443301

1620G

91	C Key Op.Code Setting(UT)		***** - *****		
92	C Auto Off On/Off Set(SP)	0	0 - 1	0	
93	C Auto Off Timer Setting(UT)	90	001 - 240	240	
94	C C:User Code On/Off Set(UT)	0	0 - 1	0	
95	C C:Key Counter On/Off Set(UT)	0	0 - 1	0	
96	C Not Used	0	0 - 1	0	
97	C P:User Code On/Off Set(UT)	0	0 - 1	0	
98	C P:Key Counter On/Off Set(UT)	0	0 - 1	0	
99	C Not Used	0	0 - 1	0	
100	C PM Alarm Interval Set:5501	0	000 - 999	000	
101	C Jam Alarm Level Set:5504-1	3	0 - 3	3	
102	C SC Alarm Level Set:5505	30	000 - 255	030	
103	C Not Used (Consumable Alarm)	0	***** - *****	0	
104	C Not Used (Consumable Alarm)	0	***** - *****	0	
105	C Not Used (Consumable Alarm)	0	***** - *****	0	
106	C Not Used (Consumable Alarm)	01000	00250 - 10000	01000	

FIG 15G

0996754 1039

1620H

107	<input type="checkbox"/> Not Used (Consumable Alarm)	01000	00250 - 10000	01000	
108	<input type="checkbox"/> Not Used (Consumable Alarm)	01000	00250 - 10000	01000	
109	<input type="checkbox"/> Not Used (Consumable Alarm)	01000	00250 - 10000	01000	
110	<input type="checkbox"/> Not Used (Consumable Alarm)	01000	00250 - 10000	01000	
111	<input type="checkbox"/> Not Used (Consumable Alarm)	01000	00250 - 10000	01000	
112	<input type="checkbox"/> Not Used (Consumable Alarm)	01000	00250 - 10000	01000	
113	<input type="checkbox"/> Not Used (Consumable Alarm)	01000	00250 - 10000	01000	
114	<input type="checkbox"/> Not Used (Consumable Alarm)	01000	00250 - 10000	01000	
115	<input type="checkbox"/> Not Used (Consumable Alarm)	01000	00250 - 10000	01000	
116	<input type="checkbox"/> CC201/202 On/Off Setting	1	***** - *****	1	
117	<input type="checkbox"/> PM Call Interval:Copy:5513-1	0300	0001 - 9999	0300	
118	<input type="checkbox"/> PM Call Interval:ADF:5513-2	0300	0001 - 9999	0300	
119	<input type="checkbox"/> PM Call Setting:Copy:5514-1	1	***** - *****	1	
120	<input type="checkbox"/> PM Call Setting:ADF:5514-2	0	***** - *****	0	
121	<input type="checkbox"/> S/N for Display Setting:5811		***** - *****	H3600300601	
122	<input type="checkbox"/> ID2 Code:5811-3		***** - *****	H36 00300601	

FIG. 15H

1620I

123	<input type="radio"/> Service Phone Number:5812-1		***** - *****	00-0000-0000	
124	<input type="radio"/> Not Used (Consumable Alarm)	0	***** - *****	0	
125	<input type="radio"/> Not Used (Consumable Alarm)	0	***** - *****	0	
126	<input type="radio"/> Not Used (Consumable Alarm)	0	***** - *****	0	
127	<input type="radio"/> Not Used (Consumable Alarm)	0	***** - *****	0	
128	<input type="radio"/> Not Used (Consumable Alarm)	0	***** - *****	0	
129	<input type="radio"/> Not Used (Consumable Alarm)	0	***** - *****	0	
130	<input type="radio"/> SADF Auto Reset Timer(UT)	10	03 - 99	10	
131	<input type="radio"/> Staple Position Adj.:SP6105	+00	-35 - +35	0	
132	<input type="radio"/> Total Counter		0000000 - 9999999	0231033	
133	<input type="radio"/> Not Used (GPC Counter)		0000000 - 9999999	0035303	

FIG 15 I

09586304 1 10300

MACHINE CONDITION DATA

OBLON, SPIVAK, ET AL
DOCKET #: 215760US28
INV: Gregory WRIGHT
SHEET 33 OF 40

L-ADP/Copier Information

Date Received	03-02-2001 09:28
Customer	Ricoh
Installed Section	Floor
Contact	Tel
Model/Serial Number	Aficio850/ H3600300601
Particular Notes	
Tag ID	NSC 850
SO / SD	RC(TEST)/ RC(TEST) Service

~1720

State Info.

No.	Item	Result
1	Paper End:P.LCT(Tray 3)	1
2	Machine Condition	2
3	SC Details	sp_wcom.c LINE:1288 VAL :-13
4	Paper Size:Tray 1	26
5	Paper Size:Tray 2	A4
6	Paper Size:Tray 3	A0
7	Paper Size:LCT(Tray 1)	26
8	Paper Size:LCT(Tray 2)	26
9	Paper Size:LCT(Tray 3)	26
10	Configuration:ADF	2
11	Configuration:Finisher	1
12	Configuration:Printer Kit	1
13	Configuration:Scanner Kit	1
14	Configuration:LCT	1

~1730

Jam History

No.	Item	Result
1	Total Paper Jams	0057
2	Total P.Jams by Tray 1	0002
3	Total P.Jams by Tray 2	0004
4	Total P.Jams by LCT(Tray 3)	0001
5	Total P.Jams by LCT Exit	0002
6	Total P.Jams by Registration	0006
7	Total P.Jams by Exit	0005
8	Total Original Jams	0079
9	Total P.Jams by Dup.Entrance	0005
10	Total P.Jams by Dup.Trans.3	0001
11	Total P.Jams by Inverter	0006
12	Total P.Jams by Fin.Entrance	0005

~1740A

FIG. 16A

1740 B

No.	Item	Result
1	No.of Scans	0038125
2	Total Copy Counter	00236302
3	Total Print Counter	00105878
4	Not Used (GPC)	00035303
5	Not Used (GPC)	00035358
6	Total Copies by Size:LT(S)	0128095

1750 A

Fig. 16 B

7	Total Copies by Size:Others	0000002
8	Total Copies by Tray 1	0104700
9	Total Copies by Tray 2	0001302
10	Total Copies by Tray 3	0002667
11	Total Copies by Tray 4	0003009
12	Total Copies by Tray 5	0027878
13	Total Copies by Tray 6	0060825
14	Total Copies by Size:A3	0000013
15	Total Copies by Size:DLT	0001484
16	Total Copies by Size:LG	0000700
17	Total Copies by Size:LT(L)	0000043
18	Total ADF Counter	0033657
19	Staple Counter	010689
20	PM Counter:Copy (SP7-617-01)	0237921
21	PM Counter:ADF (SP7-617-02)	0030127
22	PM alarm Counter (SP7-803)	0237
23	:50%~99%	0002950
24	:Full Size	0126539
25	:101%~200%	0000409
26	:201%~400%	0000008
27	:Direct Mag.	0000004
28	:Size Mag.	0000427
29	:Fixed Mag.	0003367
30	T.Copies by Text Mode	0130010
31	T.Copies by Text/Photo Mode	0000002
32	T.Copies by Photo Mode	0000080
33	T.Copies by Generation Mode	0000044
34	T.Copies by Pale Mode	0000201
35	T.Copies by Punch	0002947
36	T.Copies by Sort	0101360
37	T.Copies by Staple	0073731
38	T.Copies by Series	0000200
39	T/C by Multiple Copy :1 to 1	0006293
40	:1 to 2~5	0000923
41	:1 to 6~10	0000757
42	:1 to 11~20	0000130
43	:1 to 21~50	0000080
44	:1 to 51~100	0000026
45	:1 to 101~300	0000011
46	:1 to 300~	0000006
47	T.Copies by Duplex Copy	0037858

~1750 B

FIG. 16C

FIG. 16C

48	T.Copies by ADF	0122251
49	T.Copies by 2-side Original	0020899
50	T.Copies by Interrupt	0000360
51	T.Copies by Combine-1side	0000069
52	T.Copies by Combine-2side	0000070
53	T.Copies by Booklet Mode	0000004
54	T.Copies by Magazine Mode	0000010
55	T.Copies by Page Numbering	0000030

~ 1750C

Operation Time

No.	Item	Result
1	Operation Time(Min.)	0078
2	PM Parts Level:Developer	6
3	(PM):Oil Supply/Cleaning Web	7
4	(PM):Web Cleaning Roller	3
5	(PM):Pressure Roller	3
6	(PM):PR Cleaning Roller	3
7	(PM):HR Stripper	3
8	(PM):Dev. Filter	7
9	(PM):Toner Filter(center)	5
10	(PM):Toner Filter(front)	5
11	(PM):1st Feed Roller	3
12	(PM):1st Pick-up Roller	3
13	(PM):1st Sep. Roller	3
14	(PM):Transfer Belt	5
15	(PM):Trsf Belt C. Blade	5
16	(PM):Dust Filter	7
17	(PM):Cleaning Blade	7
18	(PM):Cleaning Brush	7
19	(PM):Grid Plate	6
20	(PM):Charge Corona Wire	6
21	(PM):Wire Cleaner	6
22	(PM):Cushion C. Corona wire	6
23	(PM):Pick-off Pawls	7
24	(PM):ADF Transport Belt	3
25	(PM):ADF Separation Roller	3
26	(PM):ADF Feed Belt	3
27	(PM):ADF Pick-up Roller	3
28	(PM):LCT 3rd Feed Roller	2
29	(PM):LCT 3rd Pick-up Roller	2
30	(PM):LCT 3rd Sep. Roller	2

~ 1760A

FIG. 16D

31	(PM):Reserved Area 1	Z
32	(PM):Reserved Area 2	Z
33	(PM):Reserved Area 3	Z

~1760B

SC History

No.	Item	Result
1	Total SC Counter	0021
2	No.of SC310	01
3	No.of SC312	01
4	No.of SC321	01
5	No.of SC352	01
6	No.of SC630	07
7	No.of SC640	03
8	No.of SC643	02
9	No.of SC738	02
10	No.of SC990	03

~1770

Sensor Output, ROM Ver., Etc

No.	Item	Result
1	No. of Registered Program	00
2	Fusing Temperature(C)	174
3	TD Sensor Output:Vt	2.09
4	ID Sensor Output:Vsg	4.05
5	ID Sensor Output:Vsp	0.41
6	APS Sensor Output Display	00000000
7	HDD1 Bad Sector:Total	00
8	HDD1 Bad Sector:Copy	00
9	HDD1 Bad Sector:Printer	00
10	HDD1 Bad Sector:Copy Server	00
11	HDD2 Bad Sector:Total	00
12	HDD2 Bad Sector:Copy	00
13	HDD2 Bad Sector:Printer	00
14	HDD2 Bad Sector:Copy Server	00
15	ROM Version:SICU	A2945604P
16	ROM Version:BCU	A2945264P
17	ROM Version:Concorde(PI)	A2325372C
18	ROM Version:HDC	A2945144
19	ROM Version:Scanner	A2945057C
20	ROM Version:ADF	B3015562D
21	ROM Version:Finisher	B3025103G

~1780A

FIG. 16E

22	Not Used(ROM Version:RMC)	B3275141
23	ROM Version:Printer	

~1780B

Copy Counter by User Code

No.	Item	Result
-----	------	--------

~1790

Not Used

No.	Item	Result
-----	------	--------

~1792

Alarm Info.

No.	Item	Result
-----	------	--------

~1794

SC Info.

No.	Item	Result
-----	------	--------

~1796

Read/Write Change Info.

No.	Item	Result
-----	------	--------

~1798

FIG. 16 F

1800

Customer Information

Customer	
Division/Department/Section	
Copier Administration	
Address	
City/State/ZIP/Country	

1810

L-ADP Information

S/N Prefix and Serial Number	A755-		
L-ADP Phone Number			
Dialing Info	Dial Type	<input checked="" type="radio"/> Tone <input type="radio"/> Pulse(20pps) <input type="radio"/> Pulse(10pps)	
	Redialing	Register: 9, 18007426449	Redial Interval Time:
		60	Redial Frequency: 2

~1820

Copier0 Information


S/N Prefix and Serial Number		Device Code: 0
Installed Section		Floor: 1
Tag ID		
Contact		Tel: 1
SO/SD	SO: 1	SD: 1
M/R Date		
Particular Notes		
M/R Information		
Installation Date		

1830

CopierN Information

S/N Prefix and Serial Number		Device Code: 1
Installed Section		Floor: 1
Tag ID		
Contact		Tel: 1
SO/SD	SO: 1	SD: 1
M/R Date		

FIG. 17



R = reference value (after test copying for installing copier)
W = display on screen without highlight
H = display on screen with highlight in first mode.

Fig. 18